Custom Interface for MusicMatch Jukebox

Mimic the controls of a CD player with X-keys.

Ingredients:
1 – X-keys 20 key (PS/2 or USB)
1 – X-keys Accessory Horizontal keys (10 pack)
1 –MusicMatch Jukebox downloadable at: www.musicmatch.com

Recipe:
1) Download and install MusicMatch Jukebox.
2) Install your X-keys following the instructions in the manual.
3) Your X-keys comes pre-programmed with the letters a-t assigned to the corresponding keys. To clear this programming put the X-keys in programming mode, select a key and enter the sequence **ESC BACKSPACE ESC ESC ESC**. After a three second pause the red indicator should light indicating the operation was successful.
4) Program the single keys down the first and fourth columns of the X-keys following the table below. Do not program anything on the second and third columns.

> **NOTE:** **CTRL+S** indicates holding down the **CTRL** key, tapping the **S** key, and then releasing the **CTRL** key. **ALT+SHIFT+←** indicates holding down the **ALT** and **SHIFT** keys while tapping the **LEFT ARROW** key.

Programming for MusicMatch Jukebox

COLUMN 1	COL 2	COL 3	COLUMN 4
Seek Backward = **ESC+LEFT SHIFT ALT+SHIFT+←**			Seek Forward = **ESC+LEFT SHIFT ALT+SHIFT+ →**
Previous Track = **ALT+←**			Next Track = **ALT+ →**
Pause = **PAUSE/BREAK**			Play = **CTRL+P**
Decrease Volume = **ESC+LEFT SHIFT ALT+↓**			Increase Volume = **ESC+LEFT SHIFT ALT+↑**
Stop = **CTRL+S**			Mute = **CTRL+M**

> **NOTE**: the **ESC+LEFT SHIFT** sequence before the function commands on the four "seek" and "volume" keys make them repeating keys.

5) Remove the single key caps with the key puller included with your X-keys and replace them with two columns of horizontal keys.

6) Print out the legend below to label your keys.

NOTE: If you decide to reprogram your X-keys to change position or function of the keys, first remove the double key cap to ensure you are programming only one switch.

Legend for MusicMatch Jukebox

◀◀	▶▶
◀◀	▶▶
▌▌	▶
↓ Volume	Volume ↑
■	⊖ (MUTE)