

DataCAD Keyboard Shortcuts

<u>FUNCTION/MENU</u>	<u>KEY(S)</u>
2LnTrim menu	(Alt)+(J)
3D Edit menu	(J)
3D Entity menu	(Shift)+(J) or (Alt)+(U)
3D Views menu	(Y) or (Shift)+(V) or (Alt)+(V)
Active layer, scroll backward to set	(Shift)+(Tab)
Active layer, scroll forward to set	(Tab)
Append selection set toggle	(Shift)+(A)
Architect menu	(A)
Cap wall ends toggle	(I)
Center screen to cursor location	(Home)
Change menu	(Alt)+(C)
Colors, scroll backward	(Shift)+(K)
Colors, scroll forward	(K)
Coordinate entry	(SpaceBar)
Copy menu (2D/3D)	(C) or (Shift)+(C)
Cursor size toggle (big vs. regular)	(+)
Curves menu	(Alt)+(A)
Digitizer	(I)
Dimension menu	(D) or (Shift)+(D)
Dimension, Linear menu	(Alt)+(D)
Directory menu	(Alt)+(Y)
Display list, regenerate	(U) or (Shift)+(U)
Display associated saved view	(Shift)+(1) to (0)
Edit menu	(;) or (Ctrl)+(C)
EditSets menu	(Shift)+(S)
Elevation, back	(Ctrl)+(PgUp)
Elevation, front	(Alt)+(=)
Elevation, left	(F11)
Elevation, right	(F12)
Enlarge menu	(Alt)+(E)
Erase last entity	(.)
Erase last group	(<)
Erase menu (2D/3D)	(E) or (Shift)+(E)
Exit	(Ctrl)+(X)
Fillets menu	(Alt)+(F)
FreeHand menu	(Alt)+(H)
Geometry menu	(Alt)+(G)
GoToView menu (2D/3D)	(V)
Grids menu	(G) or (Shift)+(G)
Hatch menu	(H) or (Shift)+(H)
Hide menu	(Shift)+(Y)
Icon toolbar toggle	(Ctrl)+(F11)
Identify	(Shift)+(I) or (Alt)+(I)
Input mode:	(Insert) + 1 : Relative Polar 2 : Absolute Polar 3 : Relative Cartesian 4 : Absolute Cartesian
Layer search toggle	(')
Layers menu	(L) or (Shift)+(L)
Line overshoot amount	(_)
Line overshoot toggle	(-)
Line spacing, set	(F)

Linetype menu	(Alt)+(L)
Linetypes, scroll backward	(Shift)+(Q)
Linetypes, scroll forward	(Q)
Line weight, decrement	(Shift)+(W)
Line weight, increment	(W)
Link Entities menu	(Alt)+(K)
Measures menu	(Alt)+(X)
Mirror menu (2D)	(Alt)+(M)
Move menu (2D/3D)	(M)
New Drawing menu	(Ctrl)+(O) or (Alt)+(N)
Object snap	(N) or (Shift)+(N)
Object Snap menu	(Shift)+(X)
Object Snap perpendicular toggle	(Alt)+(O)
Online Help	(Ctrl)+(F1)
Ortho mode toggle	(O) or (Shift)+(O)
Orthographic View	(Alt)+(0)
Pan	() () () ()
Parallel View, most recent	(Alt)+(9)
Perspective View, most recent	(Alt)+(-)
Plotter menu	(Alt)+(P)
Polygons menu	(Alt)+(R)
Previous view, restore	(P) or (Shift)+(P)
Print	(Ctrl)+(P)
Quit	(Alt)+(Q)
Reference point entry	(^)
Restore last erased entity	(.)
Restore last erased group	(>)
Rotate menu (2D/3D)	(R) or (Shift)+(R)
Save current drawing	(Ctrl)+(S) or (Shift)+(F)
Screen refresh	(Esc)
Screen refresh by layer, stop	(End)
Screen refresh, stop	(Del)
Selection set, change active	(Alt)+(1) to (8)
Snap grid spacing, set	(S)
Snap grid toggle	(X)
Snapping point entry	(~)
Stretch menu	(Alt)+(S)
Symbol, insert by name	(")
Tangents menu	(B) or (Shift)+(B)
Template menu	(T) or (Shift)+(T) or (Alt)+(B)
Text menu	(Alt)+(T)
Toolbox menu	(Shift)+(M)
ToScale menu	(Alt)+(Z)
Utility menu	(:)
Wall T intersection clean-up toggle	(\)
Walls toggle and set new wall thickness	(=)
Weld Line menu	(Alt)+(W)
Window In	(/)
World coordinate identify	(?)
Z-base or Z-height attribute entry	(Z) or (Shift)+(Z)
Zoom Extents	(Ctrl)+(-)
Zoom In	(PgDn)
Zoom Out	(PgUp)